

Easimount® Vinyl Strip Curtain System


Part Number: SA/LA#####

REQUIRED MATERIALS

- Easimount® Vinyl Strip Curtain System
 - Drill with drill bits and Phillips head bit/screwdriver
 - Marking instrument
1. Using the aluminum channel as a template, make sure channel is level and centered above opening. Bar height should allow strips to clear floor 1/4". Mark hole patterns with pencil (**Fig. 1**).
 2. Drill holes and mount channel with proper fasteners.
Note: For flush mount freezer doors, shim aluminum channel off jamb 1/4" to increase space between vinyl strips and freezer door. (see below)
 3. Insert one end cap at either end of channel.
 4. Insert strips through un-capped end of channel (**Fig. 2**).
 5. After verifying that all strips are evenly placed and overlapping properly, insert other end cap and trim strips if needed for proper floor height (**Fig. 3**).
 6. Optional: Insert self-tapping screws at each end of channel through last strip for added retention.


CLEANING

Clean vinyl curtains with soap and water on a regular basis. For stubborn stains use a 5% ethanol (Windex type product) and water. Wipe curtain and any residual fluid on floor dry.




Shim 1/4" for freezer applications

FIG. 1




ATTACH BAR(S)

FIG. 2



SLIDE IN STRIPS

FIG. 3



CAP ENDS